

## TOP LOCK #

TAC 04 -

TAC 05 -

TAC 06 -

### INSTRUCTIONS FOR HARD AND SOFT TOP LOCK ASSEMBLY

1. Remove the top from the car.
2. Remove roof hold down mounting plate and washers, preferably on the driver's side.
3. Drill 5/8 inch hole (on secondary mounting plate surface) to the rear of existing elongated hole for the hardtop.
4. File the hole out, creating an elongation of the original hole.
5. Adjust the upper nut on the mounting plate down until it contacts the upper washer.
6. Holding the plate in place, install the lower washer and nut, also making sure the flat side of the washer is to the rear.
7. Remove existing top hold down pin from the top. Replace it with the locking hold down pin.
8. Reinstall the top.
9. Push the lock on the shaft.