

DAC09 REAR DECK PROTECTOR

Installation: Note: DO NOT INSTALL ON NEW OR UNCURED PAINT (30+ DAYS)

1. Unroll protectors and lay them flat in a clean, warm spot. Allow time for protectors to "relax". We do not recommend installing if rear deck is cold or extremely hot.
2. Thoroughly clean and wax rear deck where protectors are to be applied.
3. Wipe off any dust or foreign material from rear deck and rear deck protector.
4. Rear deck protector is supplied in two pieces. They are die cut to accommodate both the hard top and the soft top.
5. Position rear deck protector around rear holddown plates and position as you smooth out bubbles. To realign or remove air bubbles, simply peel material back and reposition.
6. Remove protectors by lifting edge with finger and rolling back. Store protectors away from dust. Although protectors adhere to car very well, we recommend removing them when driving with no top.